


PHASE STABILITY OVER TEMPERATURE



Phase Change:

The electrical length for a given frequency will “shift” as a result of environmental changes. The *degree* of change is based on mechanical stresses, connector torque and thermal conditions.

The *degree* of phase shift as a result of temperature variation can be calculated by using this formula:

$$\Delta\Phi = \Phi * \left(\frac{\text{ppm}}{10^5} \right)$$

Before calculating the expected phase shift there are a few additional questions that need to be answered.

- What is the mechanical length of the assembly (ft)
- What is the frequency of interest (GHz)
- What is the electrical length at the frequency of interest (Φ)
- What is the dielectric constant of the insulation ϵ
- What is the temperature of interest ($^{\circ}\text{C}$)

Once these questions are answered the phase shift can be calculated.

For example, what would be the change in phase for a 10 ft. cable assembly of LL142 at 80°C at 18 GHz?

Step 1: Calculate the electrical length using the following formula

$$\Phi = 365.7 * \sqrt{\epsilon} * (\text{ft}) * (\text{Ghz})$$

$$\Phi = 365.7 * \sqrt{1.478} * 10 * 18 = 80,032^{\circ}$$

Step 2: Using the chart above, determine the parts per million (ppm) at 80°C.
212 ppm @80°C

Step 3: Now Solve

$$\Delta\Phi = \Phi * \left(\frac{\text{ppm}}{10^6} \right)$$

$$\Delta\Phi = 80,032^{\circ} * \left(\frac{212}{10^6} \right) = 16.97^{\circ}$$

The cable assembly will become 16.97° longer at 80°C at 18 Ghz